



编号: JK/J.K-B28S20P.01
版本: 1.0

Smart BMS with Active-Balancer

(JK-B1A8S-20P) / (JK-B2A8S-20P)

Specification and operation manual

JKBMS Technology Co., Ltd

Product warranty clause

Name : Battery Active-Balancer

Warranty period : One Year

First of all, thank you for purchasing the Battery Active-Balancer from Chengdu Jikong technology co., LTD.

Chengdu Jikong technology co., LTD. Provides quality warranty for the hardware products and accessories sold by our company. The warranty period is as shown above. During the warranty period, the company shall have the right to choose to repair or replace the whole set of products after receiving the notice of the product failure and verification. The whole set of replacement products may be new or close to new.

1. Chengdu jikong technology co., ltd. guarantees that the products are fully tested.
2. Chengdu jikong technology co., LTD does not guarantee that the products can be used without interruption during the product repair process. However, the company shall ensure that faulty products are repaired within a reasonable time.
3. The warranty period starts from the date of product delivery or the date of installation by chengdu jikong technology co., LTD. If the company's products are not installed within 30 days after the date of shipment due to the user's schedule or delay, the warranty period of the products shall be calculated from the 31st day after the date of shipment.
4. Chengdu jikong technology co., ltd. shall not provide free warranty for any product failure or damage caused by : (a) improper use or improper maintenance; (b) software, accessories, components or other items not provided by chengdu jikong technology co., LTD.; (c) unauthorized removal, modification and misuse; (d) use in excess of the scope specified in the technical specifications of the product; (e) improper transport, handling and storage; (f) failure or damage caused by other non-mass causes (e.g. earthquake, war, traffic accident, etc.).

To the extent permitted by law, the above warranty is the only express warranty and there are no other warranties, whether written or oral. Expressly disclaims any implied warranty or commercial terms.

Copyright statement

All products sold by chengdu jikong technology co., LTD. Or software and documents sold together with the hardware products are copyrighted by chengdu jikong technology co., LTD. Chengdu jikong technology co., LTD. All Copyrights in the products and documents are reserved by chengdu jikong technology co., LTD. The purchase of the product by the user does not represent any license of the user with respect to copyright. Any reproduction or sale without the written permission of Chengdu- jikong technology co., LTD is prohibited.

目 次

1 概述 OVERVIEW	1
2 主要技术参数 MAIN TECHNICAL PARAMETERS.....	1
2.1 主要技术指标 FEATURES	1
2.2 使用环境条件	错误!未定义书签。
3 连接器及接口描述 CONNECTOR AND INTERFACE.....	3
3.1 前面板连接器、LED 灯位置描述 CONNECTORS AND LED.....	3
3.2 前面板连接器、带灯开关定义描述	错误!未定义书签。
3.3 产品外型	错误!未定义书签。
3.4 尺寸 SIZE	5
4 安装方法及注意事项 INSTALLATION METHOD AND PRECAUTIONS.....	7
4.1 开箱检查及注意事项 UNPACKING INSPECTION	7
4.2 电池管理系统设备安装 INSTALLATION OF A SINGLE BALANCER.....	7
4.3 APP 安装 THE APP INSTALL.....	8
5 使用与操作 OPERATION GUIDE.....	10
5.1 使用前的准备和检查 PREPARATION AND INSPECTION BEFORE USE	10
5.2 电池管理系统上电工作 BALANCER START TO WORK	10
5.3 APP 操作说明 APP OPERATION GUIDE	11
6 一般故障分析与排除 GENERAL FAILURE ANALYSIS AND TROUBLESHOOTING.....	错误! 未定义书签。
7 安全保护措施及注意事项 SAFETY PROTECTION MEASURES AND PRECAUTIONS.....	错误! 未定义书签。
8 运输与贮存 TRANSPORT AND STORAGE	错误!未定义书签。
8.1 运输 TRANSPORT	错误!未定义书签。
8.2 贮存 STORAGE	错误!未定义书签。
附录 “一键铁锂”、“一键三元”默认参数.....	错误!未定义书签。

1 Overview

Lithium battery smart BMS is a management system tailored for large capacity series lithium battery pack. It has the functions of voltage collection, active balance of large current, overcharge overcurrent overtemperature protection, coulometer, Bluetooth communication, GPS remote and so on. It is suitable for lithium iron phosphate, lithium ternary and other battery types.

The BMS relies on the energy transfer active equalization technology with independent intellectual property rights to achieve a maximum sustained 2A balanced current. High current active equalization technology can ensure maximum battery consistency, improve battery life, delay Battery aging.

The protective panel has a companion mobile APP that supports Android and IOS operating systems. APP can connect to the protective panel via Bluetooth on your mobile phone to check the battery working status, modify the working parameters of the protective panel, control the charging and discharging switches, and so on. The protective panel is small in size, simple in operation and full in function, and can be widely used in battery PACK of small sightseeing cars, walkers, shared cars, high-power storage, base station backup power, solar power stations and other products.。

2 Main technical parameters

2.1 Features

- ◆ Supports 4-8 series battery packs;
- ◆ The parameters of overcharge, overdischarge voltage protection and overcurrent protection can be set by APP to provide short-circuit protection.
- ◆ Real-time, active equalization with 1/2A equalization current and less than 5mV voltage difference between batteries after balancing;
- ◆ support 3 temperature probes;
- ◆ The voltage range of the monomer is 1V~5V, and the precision is (+) 5mV;
- ◆ coulometer function;
- ◆ suitable for high-capacity ternary, lithium iron, and other lithium batteries;
- ◆ Bluetooth communication function, equipped with app, which can view the battery status in real time;
- ◆ support external interface RS485, CAN Bus (Customized) and GPS interface;

Smart BMS with Active-Balancer

- ◆ low voltage shutdown function to prevent battery damage

Technical indicators	B1A8S-20P /B2A8S-20P
Li-ion battery strings	3S-8S
Lifepo4 battery strings	4S-8S
LTO battery strings	6S-8S
Balance method	ACTIVE BALANCE
balance current	1A/2 A
Main circuit resistance	0.3 mΩ
Continuous discharge current	200A
MAX discharge current	350A
Overcurrent protection (adjustable)	10~200 A
Other interfaces (customized)	RS485 LCD Display Heat
Port	common port
Monomer voltage range	1~5V
Voltage acquisition accuracy	±3mV
Overcharge protection voltage	1.2~4.35V Adjustable
Overcharge release voltage	1.2~4.35V Adjustable
Overcurrent release time	2~120S Adjustable
Overdischarge protection voltage	1.2~4.35V Adjustable
Over discharge recovery voltage	1.2~4.35V Adjustable
Temperature sensor quantity	Three
Temperature sensor	YES
Short circuit protection	YES
Coulometer	YES
Bluetooth function	support IOS Andorid
GPS (optional)	Support (one of RS485 and GPS)

2.2 Service environmental conditions

- a) Operating temperature range: -40°C~70°C;;
- b) Power requirements: 10 ~ 40V.

Smart BMS with Active-Balancer

- c) Power consumption: power consumption: balanced state 10mA@100V ,
unbalanced state 6mA@100V . .

3 Connector and interface

3.1 connectors and LED

The positions of connectors and LED are shown in figure 1




图 1 Schematic diagram of connector

3.2 definition and description of front panel connector and light switch

Smart BMS with Active-Balancer

See Table 2 for the definition of B1A8S20P / B2A8S20P protection board connector and LED lamp.

表 2 连接器定义/ Table 2 Connector definition

Connector	Pin number	JK-B1A8S20P/ JK-B2A8S20P	
		NAME	definition
P1	1	B-	Total negative electrode of battery
	2	B1	1st string battery positive pole
	3	B2	2nd string battery positive pole
	4	B3	3rd string battery positive pole
	5	B4	4th string battery positive pole
	6	B5	5th string battery positive pole
	7	B6	6th string battery positive pole
	8	B7	7th string battery positive pole
	9	B8	8th string battery positive pole
	10	B+	BMS power supply
P2	Heating function interface		
P3	LCD interface		
P4	External GPS interface (RS485 interface)		
P5	External RS485 interface (Custom interface)		
P6	1	T1A	Temperature sensor pin a 1
	2	T1B	Temperature sesor pin b 1
	3	T2A	Temperature sensor pin a 2
	4	T2B	Temperature sensor pin b 2

Smart BMS with Active-Balancer

D1	Bluetooth connection indicator. When Bluetooth is connected to the protection board, the indicator is always on, and when disconnected, the indicator flashes
C-	Connected to external load or charger negative pole
B-	Connected to the negative pole of the cell

The product appearance is shown in Below




JK-B1A8S20P/ JK-B2A8S20P appearance

3.3 Size

The size of JK-B1A8S20P/ JK-B2A8S20P BMS is 153mm×136mm×17.6mm,and its Appearance and size of mounting hole are shown in figure 2

Smart BMS with Active-Balancer



dimension diagram

3.4 Weight

JK-B1A8S20P/ JK-B2A8S20P。The BMS weighs about 559g.

4 Installation method and precautions

4.1 Unpacking inspection

Unpacking inspection and precautions are as follows:

- Handle the packing box and equalizer with care and try not to put them upside down;
- Before unpacking, pay attention to whether the package is intact, such as whether there is impact trace, damage, etc;
- Take sufficient anti-static measures, such as wearing anti-static clothes, anti-static gloves and anti-static wrist strap. After full discharge, open the anti-static bag, take out the equalizer and check whether the appearance of the equalizer is intact.

4.2 Installation of BMS

JK-B1A8S20P/ JK-B2A8S20P battery management system is applicable to 4-8 string battery packs. The wiring mode of 8-string battery pack system is shown in Figure 4.




Figure 4. wiring mode of 8-string battery pack system

The wiring mode of 7-string battery pack system is shown in the figure.5

Smart BMS with Active-Balancer




figure.5. wiring mode of 7-string battery pack system

The wiring mode of 6-string battery pack system is shown in the figure. 6.




figure.6. wiring mode of 6-string battery pack system

The wiring mode of 5-string battery pack system is shown in the figure. 7.

Smart BMS with Active-Balancer




figure.6. wiring mode of 5-string battery pack system

The wiring mode of 4-string battery pack system is shown in the figure. 8.




figure.8. wiring mode of 4-string battery pack system

4.3 The APP install

By scanning the QR code shown in Figure 9, you can obtain the mobile app (Android) supporting the product. IOS mobile phone users can directly search for "JIKONG BMS" in the

app store of Apple store to download and install..



Figure 9 手机 APP 连接二维码 APP QR Code

5 Operation guide

5.1 Preparation and inspection before use

Before turning on the power supply, please make sure again that the cable connection is correct, that the power supply provided to the battery management system is within the required range, that the device is properly placed, that the circuit board is short-circuited, and so on, that the power supply of the battery management system can only be connected after making sure that it is correct, otherwise it may cause serious consequences such as abnormal work or even burning down.

5.2 Balancer start to work

The JK-B5A25S-60P battery management system does not have an on-power control switch. When the charging interface of the device is powered on, the device automatically turns on and works.

5.3 APP operation guide

5.3.1 Device operation in APP

A) Device connection

First turn on Bluetooth on your mobile phone, then turn on APP, as shown in Figure 10.

Click on the icon in the upper left corner to scan the device. The first time you connect to the APP, you will be prompted to enter the password. The default password of the device is "1234". APP will record the password automatically after the device is connected. No password is needed for the next connection. After opening the APP, you will connect automatically. The password input interface is shown in Figure .11



Figure 10. Device scan



Figure 11. Enter the password

B) Modify password and name


You can change the device name and password by clicking the pen Icon to the right of the device list after the device is connected.

Modify the device name interface as shown in Figure 12. Note that the device name only


Smart BMS with Active-Balancer

supports English or numbers, not Chinese names and Chinese characters.

The password modification interface is shown in Figure 13. To modify the device password, you must first enter the old password of the device, and only if the current password is correct can you enter the option of entering a new password. After entering the new password twice, select Confirm to complete the device password modification.




Name modification



Password modification

5.3.2 Status View


The real-time status interface is shown in Figure 14.



Real-time status display

On the Real-Time Status page, you can view information such as switch status, charging current, discharge current, temperature display, protection alarm, individual voltage, total battery voltage, maximum pressure difference, average single voltage, balanced status, balanced current, balanced line resistance, etc.

5.3.3 Parameter Settings



Parameter Settings Page Display

If you need to modify the working parameters of the protection panel, you must first click the Authorization Settings button and enter the parameter settings password. Set permissions to validate parameters. The parameter setting password factory defaults to "123456". The parameters of the BMS can only be modified after the parameters are entered correctly and the password is set. The parameter setting password and the device Bluetooth connection password are independent of each other.

On the Parameter Settings page, the working parameters of the BMS can be modified, and each parameter is interpreted as follows.

- a) One-click Lifepo4

Smart BMS with Active-Balancer

One-click Lifepo4 button can change all working parameters of the BMS to Lifepo4 battery parameters. The default values of Lifepo4 parameters are listed in the appendix. These should be adjusted for your specific battery cell specifications for proper operation.

b) One-click lithium iron

o

One-click lithium iron can modify all the working parameters of the BMS to triple battery parameters. The default values of triple lithium parameters are listed in the appendix. These should be adjusted for your specific battery cell specifications for proper operation.

c) One-click Lithium Titanate

One-click Lithium Titanate, all working parameters of the BMS can be modified to the Lithium Titanate battery parameters. The default values of the Lithium Titanate parameters are listed in the appendix. These should be adjusted for your specific battery cell specifications for proper operation.

d) Number of monomers

Number of units Indicates the number of cells in the current battery. Please set this value accurately before use, otherwise the BMS will not work properly.

e) Battery capacity

Battery capacity This value is the designed capacity of the battery.

f) Trigger Balanced Pressure Differential

When the Active Balancing switch is turned on, and when the maximum voltage difference of the battery pack exceeds this value and the current monomer voltage exceeds the balancing start voltage, Active Balancing starts until the voltage difference is lower than this value or the monomer voltage is lower than the Active Balancing start voltage. For example, set the Active Balancing trigger pressure difference to 0.010V, start Active Balancing when the battery pack pressure difference is greater than 0.010V, and end Active Balancing when it is lower than 0.01V. (It is recommended to set the balance trigger pressure difference of 0.005V for batteries above 50AH and 0.01V for batteries below 50AH).

g) Voltage Calibration

The voltage calibration function can be used to calibrate the accuracy of the BMS voltage collection. When errors are found between the total voltage collected by the BMS and the total voltage of the battery, the BMS can be calibrated using the voltage calibration function. The calibration method is to get the actual voltage from the Battery Terminals with charge / discharge OFF then enter the "actual" total battery voltage and click on the Settings button after the voltage calibration to complete the calibration. Remember to turn charge/discharge back on.

h) Current Calibration

The current calibration function can be used to calibrate the accuracy of current collection from the BMS. When errors are found between the total current collected by the BMS and the actual current of the battery, the current calibration function can be used to calibrate the BMS. The calibration method is to fill in the current measured total battery current and click on the Settings button after the current calibration to complete the calibration.

i) Single Under-voltage Protection, Single Under-voltage Recovery

j)

Smart BMS with Active-Balancer

"Single under-voltage protection" refers to the cut-off voltage of the cells. When any single Cell within the battery pack is lower than this value, a "single under-voltage alarm" is generated, and the BMS turns off the discharging MOS. At this time, the battery cannot be discharged and can only be charged. When the alarm is generated, only after all the individual voltage values exceed the value of "single voltage recovery", the BMS removes the "single under-voltage alarm" and turns on the discharge MOS.

j) Monomer Overcharge Voltage", "Monomer Overcharge Recovery"

Single Overcharge Voltage refers to the saturated voltage of the battery. As long as any single Cell voltage within the battery pack exceeds this value, 'Single Overcharge Alarm' will be generated, and the BMS will turn off the charging MOS. At this time, the battery can not be charged but can only be discharged. When the alarm is generated, only after all the individual voltage values are lower than the "single overcharge recovery" value, the BMS removes the "single overcharge alarm" and turns on the charging MOS at the same time. While not being able to charge, the Active Balancing will transfer the higher voltage cell to a lower voltage cell.

k) Auto Shutdown Voltage

The automatic shut-off voltage indicates the lowest voltage at which the BMS operates. When the lowest cell voltage in the battery pack reaches this value, the BMS shuts down. This value must be lower than "Single under-voltage protection"

l) Maximum Charging Current", "Charging Over-current Delay", "Charging Over-current Release"

When charging the battery pack, the current exceeds the "maximum charging current" and the duration exceeds the "charging Over-current delay", the BMS generates the "charging Over-current alarm" and turns off the charging MOS. After the alarm is generated, after the "charging Over-current relief" time, the BMS relieves the charging Over-current alarm and turns on the charging MOS again.

For example, set the "maximum charging current" to 10A, "charging Over-current delay" to 10 seconds, and "charging Over-current relief" to 50 seconds. When the charging current exceeds

Smart BMS with Active-Balancer

10A continuously for 10 seconds during the charging process, the BMS will generate a 'charging Over-current alarm', turn off the charging MOS at the same time, remove the 'charging Over-current alarm' 50 seconds after the alarm is generated, and turn on the charging MOS again.

m) Maximum Discharge Current", "Discharge Over-current Delay", "Discharge Over-current Release"

When the battery pack is discharged, and the current exceeds the "maximum discharge current" and the duration exceeds the "discharge Over-current delay", the BMS generates a "discharge Over-current alarm" and turns off the discharging MOS. After the alarm is generated, after the time of "discharge Over-current relief", the BMS relieves the "discharge Over-current alarm" and turns on the discharge MOS again.

Examples include setting maximum discharge current to 100A,'discharge Over-current delay to 10 seconds, and discharge Over-current relief' to 50 seconds. When the discharge current exceeds 100A continuously for 10 seconds during the discharge process, the BMS will produce a 'discharge Over-current alarm', turn off the discharge MOS at the same time, remove the 'discharge Over-current alarm' 50 seconds after the alarm is generated, and turn On the discharge MOS again.

n) Short Circuit Protection Release

When the short-circuit protection occurs, the short-circuit protection is removed after the time set by 'Release of Short-Circuit Protection'.

o) balancing starting voltage

The balancing starting voltage is used to control the voltage stage of balancing. Balancing will be triggered when the cell voltage exceeds this value and the maximum voltage difference of the battery pack exceeds the balancing trigger voltage difference.

p) Maximum balancing current

Smart BMS with Active-Balancer

The balancing current represents the continuous current of high-voltage battery discharge and low-voltage battery charging during the process of energy transfer. The maximum balancing current refers to the maximum current in the process of energy transfer, and the maximum balancing current should not exceed 0.1C. For example, 20Ah battery shall not exceed $20 \times 0.1 = 2a$.

q) "Charging over temperature protection", "charging over temperature recovery"

During charging, when the battery temperature exceeds the value of "Charge Over Temperature Protection", the BMS generates a warning of "Charge Over Temperature Protection", and the BMS turns off the charging MOS. After the alarm is generated, and the temperature falls below "Charge Over Temperature Recovery", the BMS removes the warning of "Charge Over Temperature Protection" and turns on the charging MOS again.

r) "Charging Low Temperature Protection", "Charging Low Temperature Recovery"

During the charging process, when the battery temperature is below the value of "Charging Low Temperature Protection", the BMS generates a warning of "Charging Low Temperature Protection", and the BMS turns off the charging MOS. After the alarm is generated, and the temperature is higher than "Charging Low Temperature Recovery", the BMS removes the "Charging Low Temperature Protection" warning and restarts the charging MOS.


s) "MOS Over Temperature Protection", "MOS Over Temperature Recovery"

When the MOS temperature exceeds the value of "MOS over-temperature protection", the BMS generates a "MOS over-temperature alarm" and turns off the charging and discharging MOS at the same time, so the battery cannot be charged or discharged. After the alarm is generated, and the MOS temperature reaches lower than the value of "MOS Over Temperature Recovery", the BMS will release the "MOS Over Temperature Alarm" and turn on the charging and discharging MOS again (the MOS Over Temperature Protection Value is 75 degrees C and the MOS Over Temperature Recovery Value is 65 degrees C, (these are the factory default values and cannot be modified)).

Note: Any parameter modification, please refer to the instruction manual, inappropriate parameters may make the BMS not work properly, or even damage the BMS. After any parameter modification, you need to click on the Settings button after the parameter to complete the parameter issue. When the BMS successfully receives the parameter, it will make a "drop" sound.

5.3.3 BMS control

The BMS control page is shown in Figure 40. The BMS control can switch the charging , discharging, and balancing functions of the BMS and restore the factory settings



BMS control page

6 6. Safety protection measures and precautions

Please read the operation manual carefully before use, and connecting the wires according to the wiring diagram of the corresponding string number, from the negative pole to the positive pole. After the balancing wire is connected, use a multi-meter again to confirm that it is correct before connecting the BMS.

The default password of the BMS is "**1234**". After the mobile app is connected to the BMS, please modify the connection password in time to prevent others from connecting.

It is not allowed to refit the power line of the BMS without permission. Refitting the power line without permission will cause uneven Over-current of the BMS and damage the BMS.

7 7. Transportation and storage

8 7.1. Transportation

8.1 The packed product is not directly affected by rain or snow and is subject to severe bumps. It can be transported by normal means of transport. Corrosives such as acids and bases are not allowed to be kept together during transportation.

9 7.2. storage

The packed products should be stored in a permanent warehouse with a temperature ranging from 0 35 and a relative humidity not exceeding 80%. The warehouse should be free from acid and alkali, corrosive gases, strong mechanical vibration and impact, and strong magnetic field.

Smart BMS with Active-Balancer

Appendix1 Default Parameters for Lithium-Ion, Lithium Iron Phosphate, Lithium Titanate

NUM	PARA	LI-ION	LIFEPO4	LTO	UNIT
1	Single under-voltage protection	2.9	2.7	1.8	V
2	Single under-voltage protection recovery	3.2	2.9	2.0	V
3	Monomer Overcharge Voltage	4.2	3.6	2.7	V
4	Monomer Overcharge Protection Recovery	4.1	3.5	2.4	V
5	Trigger Balanced Pressure Differential	0.01	0.010	0.01	V
6	Auto Shutdown Voltage	2.8	2.6	1.7	V
7	Charging Over-current Protection Delay	30	30	30	S
8	Charging Over-current Protection Release Time	60	60	60	S
9	Discharge Over-current Protection Delay	30	30	30	S
10	Discharge Over-current Protection Release Time	60	60	60	S
11	Release time of short circuit protection	60	60	60	S
12	Charging Over-Temperature Protection Temperature	60	60	60	°C
13	Charging Over-Temperature Recovery Temperature	55	55	55	°C
14	Discharge Over-Temperature Protection Temperature	60	60	60	°C
15	Discharge Over-Temperature Recovery Temperature	55	55	55	°C
16	Charging Low Temperature Protection Temperature	-20	0	-20	°C
17	Charging Low Temperature Recovery Temperature	-10	5	-10	°C
18	MOS Over-Temperature protection temperature	75	75	75	°C
19	MOS Over Temperature Protection Recovery Temperature	70	70	70	°C

Smart BMS with Active-Balancer

Appendix II key points for parameter setting of the BMS

NUM	parameter	UNIT	MIN	MAX	Li-ion	Lifepo4	NOTE
1	Number of monomers	Strings	2	-	-	-	The maximum value refers to the model of the BMS. The default value is the maximum number of strings supported by the model
2	Battery capacity	AH	5	2000	40	40	
3	Trigger Balance Pressure Differential	V	0.003	1	0.01	0.01	
4	Single under-voltage protection	V	1.2	4.35	2.9	2.6	These parameters must follow the following logical relationship. Otherwise, you will be prompted that the parameter setting fails!
5	Single under-voltage recovery	V	1.2	4.35	3.2	3	
6	Single overcharge voltage	V	1.2	4.35	4.2	3.6	
7	Monomer overcharge recovery	V	1.2	4.35	4.1	3.4	Cell overcharge voltage > cell overcharge recovery > cell under-voltage recovery > cell under-voltage > shutdown voltage
8	Automatic shutdown voltage	V	1.2	4.35	2.8	2.5	
9	Maximum charging current	A	1	-	25	25	The maximum value refers to the model of BMS,
10	Charging Over-current delay	S	2	600	60	60	
11	Charging Over-current release	S	2	600	60	60	
12	Maximum discharge current	A	1	-	-	-	The maximum value refers to the model of the BMS, and the default value is the continuous current supported by the model
13	Discharge Over-current delay	S	2	600	300	300	
14	Discharge Over-current release	S	2	600	60	60	
15	Short circuit protection delay	uS	0	1000000	1500	1500	Set to 0 to turn off short circuit protection
16	Short circuit protection release	S	2	600	60	60	
17	Maximum balancing current	A	0.3	-	-	-	The maximum value refers to the model of the BMS. The default value is the maximum Active Balancing current supported by the model
18	balancing starting voltage	V	1.2	4.25	1.5	1.5	
19	Charging over temperature protection	°C	30	80	70	55C	These parameters must follow the following logical relationship, or you will be prompted that the parameter setting fails! Charging over temperature > charging over temperature recovery > charging low temperature recovery > charging low temperature Discharge over temperature > discharge over temperature recovery
20	Charging over temperature recovery	°C	30	80	60	50~55 C <0.1C	
21	Discharge over temperature protection	°C	30	80	70	55C	
22	Discharge over temperature recovery	°C	30	80	60	50C	
23	Charging low temperature protection	°C	-30	20	-20	0C	
24	Charging low temperature recovery	°C	-30	20	-10	0~10C max current 0.2c	
25	MOS over temperature protection	°C	50	110	90	90	Not modifiable
26	MOS over temperature recovery	°C	50	110	70	70	Not modifiable
27	User private data	character	-	-	-	--	Maximum 13 characters allowed
28	Connecting line resistance	mΩ	0	2000000	0	0	Separate box batteries are used, and single box batteries are generally not used.

Be careful:

1. Factory default Li-ion parameters.
- 2 It is recommended that users only modify the number of individual strings and the capacity of individual. Then select one-click settings according to the battery type. If other parameters need to be modified, users are strongly advised to read the instructions to understand the meaning of each parameter before modifying them.
3. If you modify according to the above rules and prompt for errors, it is recommended that users update APP.

Noted:

1. For Android 12 and above systems, app needs to be allowed to obtain mobile GPS permission, and it is always allowed.
(this is the setting of Android 12 system. BMS will not always read the user's data.)
2. It is recommended that the customer update the app in time. The app will repair the bug within a week according to the customer's feedback, and it will also be updated according to the design reasons.

FAQ:

Error code

1. Monomer over discharge alarm
2. Monomer overcharge alarm
3. Overcurrent alarm
4. MOS over temperature alarm
5. CELL over temperature alarm
6. Short circuit alarm
7. Internal communication abnormal alarm
8. Alarm of excessive equalizing resistance
9. Drop string

Supplemental Appendix

System Calibration for proper BMS operations.

Calibrating the Voltages between your Solar Controller, Inverter/Charger, All-In-One Must be Done.

- This is essential so that everything is reading, sending/receiving the correct Voltages @ the Battery Terminals / DC Bus (for Parallel Banks of Batteries).

- When an SCC or Inverter/Charger etc is charging @ 25.6/51.2 You need to ensure that is WHAT the Batteries See. Otherwise, the differential "will" cause a Mismatch and generate an error (*1), either at the SCC or any Charge Device on the DC Bus (*2).
- The BMS is the MOST Precise @ measuring the Battery & the Cell Voltage States. This applies to a Single Battery or a Bank of Batteries.
- Not All SCC's or Charging Devices have a Compensation/Correction setting within them. Therefore you have to do the "Math" to compensate for that differential. Therefore you "must" take Voltage Measurements @ the SCC, Charger & Battery Terminals/Bus, then make adjustments to match your desired Charge Profile to prevent such incidents.
- A Digital Multimeter / Digital Volt/Ohm Meter with at least 2 Decimal Place voltage displays is Most Highly Recommended to do so. A Single Digit device is TOO INACCURATE for any Lithium Based Battery or cell.

(*1) This can result in Over/Under voltage reading triggering an error. IF over or under it can also create the "Runner Cell" situation where one or more cells within a Battery can run & defeat the Working Voltage Range (3.000-3.400) of the cells, triggering a BMS Fault. This is Very Common with new/fresh installations that are NOT Corrected & Balanced for Voltage.

(*2) Note that ALL DC-Lines will suffer some loss over the length of the wire run. These include every terminal, lug, bolt, switch, and even fuses & breakers collectively. While each individual "item" may not be large (unless there is a Fault), collectively they can add up quite quickly collectively. This is an "accuracy" requirement problem with using Lithium Based tech as opposed to Lead Acid which is more "brute force" and not as accurate due to the very Tight Voltage Curves in comparison to Lead-Acid.

Typical Faults creating large drops, with some basic problem avoidance solutions:

- Loose or dirty connections,
- Poor or weak crimped terminals,
- Overly long wiring, including wires of Different Lengths (+) & (-) should be as close to identical lengths as possible,
- Low-Grade or Incorrect wiring used for the application, load & demands,
- Quality wires (Fine Strand Pure Copper) tinned or not, along with Tinned Terminal lugs is always the best solution,
- All Connections to Lugs etc should be shrink wrapped with quality adhesive bound Shrink Wrap to prevent air/moisture infiltration over time that can cause corrosion & deterioration. Do NOT avoid using long enough shrink wrap.

Final Important Note:

It is extremely important to not that various devices like Solar Charge Controllers, Inverter/Chargers etc all have varying hardware, firmware and user interface software. This makes Calibration & Configuration more demanding for proper operations between all the variety of devices.

Repair instructions

1、Processor exception

appearance(CPUAUX Anomaly)




Product appearance



Testing repair method:

Step 1: Test the resistance between A and B points in the figure when the machine is not turned on. If the resistance is less than 100 Ω, it is necessary to replace chip C, which is RY3820E. After replacing the chip, retest the resistance between A and B in the figure. If the resistance is greater than 100 Ω, restart the machine for test; Confirm whether the functional fault is eliminated. If the fault persists, the second step is required.



Step 2:After power on, test the voltage between A and B points in the diagram. If the voltage is between 4.5~5.2V, it is necessary to replace chip D, which is MDT10F272. After switching off and replacing the chip, turn on the machine again to test whether the functional fault is eliminated.

2、 The number of monomer is inconsistent with the set value appearance(CELL Count is not equal setting)

product appearance



Testing repair method:

Step 1: Test the resistance between A and B points in the figure when the machine is not turned on and the battery is not connected. If the resistance value is greater than 2 Ω, replace the resistance between A and B, and the resistance value is 10m Ω; Perform the second step after replacement.

Step 2: When the machine is not turned on and the battery is not connected, adjust the multimeter to the diode test gear (as shown by arrow A1) and perform the following tests:


Test point B with the black multimeter and point C with the red multimeter. If the displayed value is within the range of 0.3~0.7, it is qualified.

Test point C with the black multimeter and point B with the red multimeter. If it shows that the range is exceeded, it is qualified.

Test point D with the black multimeter and point C with the red multimeter. If the displayed value is within the range of 0.3~0.7, it is qualified.


Test point C with the black multimeter and point D with the red multimeter. If it shows that the range is exceeded, it is qualified.

If the test value is not within the range, the corresponding MOS tube is damaged and needs to be replaced (model: HYG180N10LS1S). After the replacement, repeat the second step. After the above values are qualified, the machine can be started for test.




Note: If other channels are damaged, repeat step 1 and step 2 according to the corresponding relationship identified in the figure below, and give priority to the lowest string of exceptions. As shown in the figure, the abnormal channels are 08 and 09, and priority should be given to maintenance of CH8.

PCB Front side



PCB back side



3、Unable to start

Product appearance




testing repair method:

Step 1: Try to start the machine after replacing the IC1. If the fault is not eliminated after replacement, perform the second step.

Step 2: Test the resistance between A and B points in the figure when the machine is not turned on and the battery is not connected. Then test the resistance values at both ends of C1, C2 and C3 capacitors. The test results and corresponding processing methods are shown in the following table.


	Testing results and handling methods	
	Processing method for $< 500 \Omega$	Processing method for $> 500 \Omega$
C2	Replace IC2 (RY3820E)	do no handle
C3	Replace IC3 (RY3820E)	do no handle

PCB front middle part
PCB back Left middle part



4、Over temperature protection

Appearance(Charge over Temp)



product appearance



Testing repair method:

Step 1: replace the temperature sensor and test again. If the fault is not found, go to step 2

Step 2: Replace the IC1 shown in the figure below

